$$L_{full} = \frac{MotorHP}{\left[\eta_{motor,full} \middle/ 100 \right]} - MotorHP$$